

# CLEANING & MAINTENANCE

**PLEASE READ** these instructions below for cleaning and maintenance PaviFLEX products.

Once installed and before using the floor :

(1) Sweep the floor and then mop the floor with normal standard soap. Please **DO NOT USE ABRASSIVE PRODUCTS**. A hard brush to be applied with water and neutral soap might be needed for non-slip products like PaviGOM and EcoFLEX.

(2) Deep Stains: For deep stains and tough stains you need to use any standard **DEGREASER** in the market. We recommend KH-7. Apply the degreaser on the stain with hard brush during 10 seconds, and clean with water and neutral soap. Repeat if needed.

## MAINTENANCE

- For products like Aerobic, Fitness, Mat030, Tatami, Stretching and Junior just apply a soft mop regularly.
- For non-slip products PaviGOM and EcoFLEX, mop regularly. A hard brush might be needed.

**DO NOT USE ABRASSIVE CLEANING PRODUCTS**

For assistance please contact by phone: +34965403300 or email: [info@paviflex.es](mailto:info@paviflex.es)